Recessed Handle Installation Instruction Sheet PC-359 * Please be sure to read before installing product. * Do not dispose the installation sheet after installation, instead please pass it to the product user. PC-359 Notch Dimension 2 30. 225.5 ▲ Caution: About installation * Product will be loose if installed in a notch that is bigger than what is stated.

** Do not install product onto a hollow door. * Although this is the recommended dimension, do note that adjustments may be needed depending on the material of the door. KAWAJUN * After installation, please check to ensure product has been installed securely. www. kawajun. co. jp NO. 001