

## Door Stop Installation Manual

※Please read the instructions before proceeding with installation.

Please hand this manual to the end user after installation. AC-875

### ■ Floor Installation


※Please ensure that the bumper is facing the door during installation. Check the swinging angle of the door to ensure that there is contact with the bumper before installation.

#### ● Concrete Floor

① Drill a hole for the anchor plug then hammer  $\phi$  12-35(AC-0835X0415) gently into the hole.



② Screw in the M8 screw with spring washer then screw in the anti-rotation screw.

Ensure that the anchor plug is fully in the floor before screwing the M8 screw in to ensure that the product sits flush on the floor.





#### ● Wooden Floor

① Attach the body into the floor with the wood screws provided (3 locations). Insert the bumper from the door side and ensure that it is secured in place.



### ■ Dimensions (mm)



#### ※Removing Bumper

Use a flathead screwdriver. Insert the tip into the gap between the body and bumper then apply prying motion to remove it. To prevent scratches, cover the tip with a piece of cloth.

### ⚠ Precautions for Usage

- The load capacity of this product is 60kgf. If a higher load is applied, the product may be damaged and cause injury.
- To clean the product, wipe it lightly with a soft, dry cloth. If the surface is heavily soiled, wipe with a cloth containing water or neutral detergent diluted with water (about 5-10%), and then wipe dry with a dry cloth. Do not use benzene, thinner, alcohol, toilet detergent, fungicide, chlorine detergent, acid or alkaline detergent, or cleanser.